

ECU	Description	Engineering Assy P/N	Software P/N
ABS	Anti-Lock Brake System	LK9C-2C219-CD	LK9C-2D053-CD
ACCM	Air Conditioning Control Module	LJ9H-19F611-AB	LJ9H-14D491-AB
ACM	Audio Front Control Module	LJ8T-18K810-DHG	JX7T-14C302-BNS
APIM	SYNC Module	DSMU5T-14G670-EJ	MU5T-14G676-EJ
BCM	Body Control Module	MU5T-14B476-RCR	MU5T-14C184-ACM
BCMC	Body Control Module C	LJ8T-14D068-HAC	L1MT-14G630-BJ
BECM	Battery Energy Control Module	NJ98-10B687-BB	NJ98-14C197-BB
BECSMB	Battery Energy Control Module B	HU5T-14G490-AF	HU5T-14G499-AE
CCM	Cruise Control Module	ML3T-9G768-AL	ML3T-14D049-AL
CMR	Camera Module - Rear	LJ8T-3G590-XH	ML3T-3G604-MD
DCDC	Direct Current/direct Current Converter Control Module	LJ98-14B227-AF	LJ98-14D459-AC
DCME	Door Control Module E	LJ8A-14G459-CJ	LJ8A-14G470-AH
DCMF	Door Control Module F	LJ8A-14G458-CJ	LJ8A-14G463-AH
DCMG	Door Control Module G	LJ8A-14G461-AJ	LJ8A-14G484-AH
DCMH	Door Control Module H	LJ8A-14G460-AJ	LJ8A-14G477-AH
DDM	Driver Door Module	JX7T-14B531-BC	JX7T-14C064-BC
DSM	Driver Front Seat Module	MU5T-14C708-BG	MU5T-14C030-AH
DSP	Audio Digital Signal Processing Module	M1PT-18B849-AM	M1PT-14C589-AM
GFM	Generic Function Module	LJ8B-14F008-AE	LJ8B-14H121-AE
GSM	Gear Shift Module	LJ9P-7P155-AJ	LJ9P-14G395-AG
GWM	Gateway Module A	DSMU5T-14G650-ED	LJ8T-14H021-EKL
HCM	Headlamp Control Module	LJ8B-13C148-AD	ML34-14D063-AD
HVAC	Heating, Ventilation And Air Conditioning	LJ8T-18C612-AK	LJ8T-18D619-AJ
IPC	Instrument Panel Cluster	DSLJ8T-1A292-AK	LU5T-10F906-AA
IPMA	Image Processing Module A	LJ8T-14G647-FT	ML3T-14H102-GAP
OBCC	Off-Board Charger Controller	LJ98-14G568-AN	LJ98-14G684-AM
OCSM	Occupant Classification System Module	LJ8B-603B16-AD	LJ6B-14F595-AA
PACM	Pedestrian Alert Control Module	LJ8T-14G113-DA	ML3T-14G492-BB
PCM	Powertrain Control Module	MJ98-12A650-BBJ	MJ98-14C204-BBJ
PDM	Passenger Door Module	JX7T-14B533-BC	JX7T-14C108-BC
PSCM	Power Steering Control Module	LJ9C-3F964-BB	LJ9C-14D003-AM
RCM	Restraints Control Module	LK9T-14B321-AA	LK9T-14C028-AA
RFA	Remote Function Actuator	MU5T-14G617-AN	MU5T-14G623-BC
RGTM	Rear Gate Trunk Module	JX7T-14B673-BB	JX7T-14C121-AP
SCCM	Steering Column Control Module	LB5T-3F944-DE	LJ8T-14C579-AB
SOBDM	Secondary On-Board Diagnostic Control Module A	LJ98-10B689-AT	LJ98-14F476-AS
SOBDMB	Secondary On-Board Diagnostic Control Module B (SOBDM)	LJ98-7S008-DD	LJ98-14H297-DD
SOBDMC	Secondary On-Board Diagnostic Control Module C	LJ98-7P120-BBG	LJ98-14G069-BBG
SODCMC	Side Obstacle Detection Control Module C	ML3T-14H031-DH	ML3T-14H094-DH
SODCMD	Side Obstacle Detection Control Module D	ML3T-14H031-CH	ML3T-14H094-CH
SODL	Side Obstacle Detection Control Module LH	ML3T-14H031-BH	ML3T-14H094-BH
SODR	Side Obstacle Detection Control Module RH	ML3T-14H031-AH	ML3T-14H094-AH
TCU	Telematic Control Unit Module	DSMU5T-14H074-AAX	MU5T-14H085-DG
WACM	Wireless Accessory Charging Module	M1PT-19J235-AA	LL1T-14G583-AA







